


Model 2015F Mattress Filling Machine

A quick and easy solution to producing foam, cotton, & inner-spring mattresses.

Mattress Filling Machines



Specifications

- Opposing upper & lower chain rails convey inner materials (e.g. foam, cotton, innersprings) into a pre-fabricated mattress covers
- Filling time of approximately 11sec after loading inner materials
- Motorized spout width...
Crib: 18-40in / Std: 24-60in / King: 24-76in
- Motorized spout thickness...
Adjustable from 4-10" thick
- Heavy-duty foot switch controls chains
- Easy-access, swing-arm-mounted control box houses height & width switches
- Lockable, UL489-rated disconnect switch
- Optional piece counter
- 200-240VAC, 3-Ph, 50/60 Hz, 24 FLA

Operation

1. Adjust the spout width & thickness to match the size of your mattress.
2. Pull a pre-sewn cover/ticking over the spout (front end of the machine).
3. Place the inner materials in the loading area (rear end of the machine).
4. Hold the cover & press the foot switch to fill the materials into the cover.



5559 National Turnpike, Louisville, KY 40214 USA
Phone: (502)366-0407 Fax: (866)927-9034
Email: info@drcashinc.com Web: www.drcashinc.com